

Flujómetro de Sensor Electrónico  
de Embolo de Baterías para Mingitorio  
de 19 mm con Botón Accionador Mecánico

3/4" Sensor Flushvalve Battery Operated  
with Manual Flush Button

Mod. FB-185-19

No.	Clasif.	Descripción	No.	Clas.	Description
1	Rf-317-C	Cúpula Ciega Fluxómetro Nuevo	1	Rf-317-C	Valve Cover with O'Ring
2	Rf-016	Rondana Neopreno Cúpula Flux.	2	Rf-016	Neoprene Cover Washer
3	Rf-015	Tornillo 8-32 Unc-2Ax12"	3	Rf-015	Brass Screw Spindle Piston
4	Rf-294	Rondana de Latón 3 Lts.	4	Rf-294	Brass Washer Sleeve Armed
5	Rf-052	Llantita S-14-A Vulcanizada	5	Rf-052	Double Lip Washer S-14
6	Rf-325	Embolo Macho del Rin 3 Lts.	6	Rf-325	3L Male Piston
7	Rf-234	Resorte Embolo Llave Reten.	7	Rf-234	Piston Spring
8	Sf-102	Asiento con Perno Embolo	8	Sf-102	3L Seat And Stem
9	Rf-005	Rondana Hule Embolo Hembra S-20	9	Rf-005	Rubber Washer for Piston Nut Seat
10	Rf-232	Embolo Hembra 6 Lts.	10	Rf-232	Female Piston Nut
11	Rf-075	Rondana S-21 Vulcanizada	11	Rf-075	Vulcanized Rubber Washer Sv-21
12	Sf-531	Cpo. Princ. Arm. Flux. Elec. c/Botón	12	Sf-531	Flux Main Body Assy W/Button
13	Rf-539	Tapa Botón para Fluxómetro	13	Rf-539	Flush Valve Button Cap
14	Rh-220	O'ring 2-115	14	Rh-220	O'ring 2-115
15	Rf-336	Cpo. Estopero Flux. Electrónico	15	Rf-336	Stopper Body Electronic Flush Valve
16	Rf-338	Resorte Perno Flux. Elect.	16	Rf-338	Spring Bolt
17	Rf-339	Tuerca Perno Flux. Elect.	17	Rf-339	Nut For Bolt
18	Rf-340	Arandela Goma Llantita	18	Rf-340	Handle Metal Washer
19	Rf-341	Goma Llantita Flux. Electrónico	19	Rf-341	Small Tire Electronic Flush Valve
20	Rf-300	Perno Asiento Flux.Pilas y C	20	Rf-300	Stopper Seat Electronic Flush Valve
21	Rr-023	O'ring 2-024	21	Rr-023	2-024 O'Ring
22	Rf-497	Cople Int. Niquelado Flux. Bat.	22	Rf-497	Interior Coupling Electronic Flush Valve
23	Rf-494	Filtro para Flux. de Pila	23	Rf-494	Rollod Filter
24	Rh-002	O'ring 2-012	24	Rh-002	2-012 O'ring
25	Rf-344	O'ring 2-025	25	Rf-344	2-025 O'Ring
26	Rf-496	Cople Externo con Alojamiento	26	Rf-496	External Coupling
27	Rf-032-C	Tca. Unión Cople Cpo. Principal	27	Rf-032-C	Handle Nut
28	Rh-217	O'ring 2-118	28	Rh-217	2-118 O'ring
29	Rf-554	Porta Electroválvula	29	Rf-554	Solenoid Valve Holder
30	Ra-637	Tornillo Allen 8-32 X 5/16"	30	Ra-637	8-32 X 5/16" Allen Screw
31	Sv-359	Electroválvula 6 Volts	31	Sv-359	6V Solenoid Valve
32	Rh-217	O'ring 2-118	32	Rh-217	2-118 O'ring
33	Rf-525	Tornillo Allen 5-40 X 1/2"	33	Rf-525	Allen Screw 5-40X1/2"
34	Rf-483	Tapa Sensor para Flux. de Pila	34	Rf-483	Battery Flush Valve Sensor Cap
35	Rf-480	Empaque Sensor Flux. Pila	35	Rf-480	Flush Valve Rubber Washer
36	Rf-558	Carcaza de Pilas	36	Rf-558	Battery Casing
37	Rf-532	Tornillo para Carcaza	37	Rf-532	Allen Screw Stop Body
38	Rf-120	O'ring Parker No. 2-006	38	Rf-120	O'Ring 2-006
39	Rf-531	Inserto para Carcaza	39	Rf-531	Casing Insert
40	Rf-555	Porta Sensor	40	Rf-555	Sensor Holder
41	Sf-556	Sensor para Fluxómetro Pilas C1019/200	41	Sf-556	C10 19/200 Flush Valve Sendor
42	Rv-089	Rondana de Hule Tapón Cespól	42	Rv-089	Rubber Washer Stopper
43	Rf-565	Tapón para Carcaza	43	Rf-565	Housing Cap
44	Rf-481	Empaque Tapa Batería Flux.	44	Rf-481	Traduccion
45	Rf-482	Tapa Batería Fluxómetro Pila	45	Rf-482	Battery Flush Valve Cap
46	Rv-660	Pila de Litio 6V	46	Rv-660	Lithium Battery
47	Sv-362	Porta Pilas Rio01	47	Sv-362	Waterproof Battery Holder
48	Rf-519	Resorte Compresión Botón Flux.	48	Rf-519	Traduccion
49	Rf-120	O'ring 2-006	49	Rf-120	O'Ring 2-006
50	Rf-523	Perno para Fluxómetro	50	Rf-523	Flush Valve Stopper
51	Rf-521	Botón Manual Fluxómetro Elect.	51	Rf-521	Traduccion
52	Rf-522	Tuerca Alojamiento Fluxómetro	52	Rf-522	Flush Valve Nut
53	Rv-071	Rondana para Esparrago Val.	53	Rv-071	Rubber Washer
54	Sf-009-C	Niple Recto Reducción 32-19	54	Sf-009-C	32-19Mm Reduction
55	Rf-063-C	Tuerca F2-32	55	Rf-063-C	Main Body Nut 32 Mm
56	Rf-080-C	Tuerca Spud 19 Mm.	56	Rf-080-C	19Mm Spud Nut
57	Rf-081	Rondana Tuerca Spud de 1	57	Rf-081	19 Mm Fiber Washer
58	Rf-249	Chap. Chico de 19 Mingitorio	58	Rf-249	19Mm Small Escutcheon
59	Rf-037-C	Tuerca Cople Llave Retención	59	Rf-037-C	Coupling Nut For Stop Body
60	Rf-036	Anillo Presión Niple Extensión	60	Rf-036	Pressure Ring For Tail Piece
61	Rf-035	O'ring 2-123	61	Rf-035	O'ring 2-123
62	Rf-248	Chapetón Chico de 32 Llave Ret	62	Rf-248	Stop Body Escutcheon
63	Rf-038-C	Cuerpo Llave Retención 1	63	Rf-038-C	Stop Body 1"
64	Rf-256	Inserto Embolo y Asiento Tope	64	Rf-256	Seat Stop And Piston Insert
65	Rf-234	Resorte Embolo Llave Reten.	65	Rf-234	Piston Spring
66	Rf-250	Embolo Llave Retención	66	Rf-250	Delrin Piston
67	Rh-220	O'ring 2-115	67	Rh-220	O'ring 2-115
68	Rf-040	Guía Delrin Embolo	68	Rf-040	Delrin Piston Guide
69	Rf-041-C	Tornillo Elevador Llave Ret.	69	Rf-041-C	Elevator Screw
70	Rf-042-C	Tuerca Superior Llave	70	Rf-042-C	Stop Body Upper Nut
71	Rf-546	Tapón para Llave de Retención	71	Rf-546	Stopper For Stop Valve
72	Rv-456	Llave Allen 3/32"	72	Rv-456	3/32" Allen Wrench
Sub-ensamble:			Sub-assemblies:		
73	Sf-015-C	Embolo Llave Retencion	73	Sf-015-C	Shut Off Assembly System
74	Sf-008-C	Llave Retencion Arm. sin Cromo	74	Sf-008-C	Stop Valve
75	Sf-105-C	Cupula Ciega Flux. N-54-N	75	Sf-105-C	Valve Cover with O'Ring
76	Sf-170	Embolo Arm. Flux Elect. 6 Lts.	76	Sf-170	Assembled Piston
77	Sf-077-C	Rondana y Tuerca Spud 19	77	Sf-077-C	19Mm Nut and Washer
78	Sf-157	Perno Armado Niq.Flux.Elect.	78	Sf-157	Electric Flush Valve Piston
79	Sf-177	Cople Interior con Perno Arm.	79	Sf-177	Internal Coupling
80	Sf-557	Dispositivo Electronico Fluxometro de Pilas	80	Sf-557	Electronic Flush Valve System

